



FOOT WARMER INSTRUCTIONS FOR USE WITH THE FOUR ZONE CONTROL or POWER DEMON

210116_210105

THE SYMTEC FOOTWARMERS COME IN TWO CONFIGURATIONS: BATTERY PACK (6 VOLT) AND 12 VOLT FOR USE ON Snowmobiles, ATVs, and Motorcycles.

Included is a wiring harness which you will need to attach to your ATV.

WIRING for use with the SYMTEC FOUR ZONE CONTROL:

1. Plug in wiring harness into the AUX 1 or AUX 2 channel of the FOUR ZONE Control.
2. Route the main wire from the Wiring Harness along the handlebar and secure the wiring in place using tie wraps. **MAKE CERTAIN THERE IS SUFFICIENT STRAIN RELIEF TO ASSURE THAT THERE IS NO INTERFERENCE WITH THE STEERING.**
3. Route the wires down each side of the frame such that the connectors are convenient for plugging in the connector on the foot warmers.
4. Secure the wires to the ATV such that the plugs are conveniently located for you to plug in the foot warmers from each boot.
5. Start your ATV and set the power level on the AUX1 or AUX 2 depending on what channel you have plugged the foot warmers into.

WIRING for use with the Optional Symtec 210097 (battery cable w/fuse on/off switch) which allows you to connect your foot warmers to battery of your vehicle.

1. Remove the seat and plan your wire routing from the battery to the front of your machine where you want to locate the connectors for easy connecting.
2. Connect the cable assembly to the battery.
3. Secure the cable in place using the supplied tie wraps.
4. Plug in your foot warmers and enjoy the comfort. Should you want to upgrade to a power control, watch our website for our new single channel power controller for heating items.

Symtec Inc.

6227 University Avenue NE
Fridley, MN 55432

Phone: 763-571-9193 www.symtec-inc.com

210116_210105_1 Rev 8/6/09
